




Window Measuring Guide



Identify where you want the blinds to be installed: inside the frame or outside the frame.

Inside frame:

- measure **left, centre, and right side** from the base of the frame and top of the frame.



- measure **top, middle, and bottom** from the left to rightside of the frame.



Outside frame:

For the blind's headrail to be attached on the window frame, measure the **width** of the frame where you want the headrail to sit.

NOTE: if the height and width measurements vary, use only the smallest measurement.

